

The i5 Plus Smartband

User Guide

Requirements

- Android:
- 1) Bluetooth 4.0;
 - 2) Android 4.3 or above.
- IOS:
- 1) IOS 8.0 or above.

Features

Time: 23:15(Landscape)

Steps: 58(Portrait)

Date(mm/dd): 10/26

Day: --

Clock: 12

Idle remind: 1

Bluetooth Connection: 1

Phone search: 1

Steps: 58

Sleep monitoring: 1

Call notification: 1

Remote Camera: 1

Setting: 1

Calories: 1

Message Notification: 1


Bluetooth Broadcast: 1

Power off: 1

Landscape and portrait orientation: 1

Charging

When using i5plus for the first time Please press and hold the screen to switch on the device, or charge the device if the screen does not display. Take off the body of smartband as shown in the picture below,plug it into the USB port(5V/500mA or above), e.g., computer, USB adapter, power bank. The white light flashing means it is charging, and disappear after about 45 minutes.



Application download

Search "Zeroner Health" on Apple store or Google Play. Or scan the QR Code below.



Registration

Open the App and register by email as Username. registered user could directly login.

Control

Raise hand or touch screen to display. Operation.

Functions	Operation
Power on	
Display	

For more features please download "Zeroner Health" App.

Syncing data

The data and time will automatically update when the bracelet connecting with phone, syncing data includes : steps, calories, sleep status (if sync successfully), after synced data, the app display the syncing states. First time syncing takes about 1-2 minutes. Or click the Home page of app to manual sync.

Switch off	Swipe left and right to , and find then hold and press to switch off.
Level directory	Left and right swipe
Secondary directory	Tap screen
confirm	Press and hold
Phone finder	(this function is available while phone and smartband still connected) Press and hold then press and hold until vibrating once.
Enter sport mode	: Running/walking, : push-up, : Rope skipping, : basketball, : sit-up. Swipe to the above modes, press and hold to enter until once vibrating,icon flashing means entering the chosen mode.
Sport mode confirm	Left and right swipe to , then swipe to , then press and hold until enter to icon.
Enter to sleep mode	Left and right swipe to , then swipe to , then press and hold until enter to icon.
landscape and portrait orientation	Left and right swipe to , then swipe to , then press and hold until vibrate once.